

Installing The First Deck Board

1. Apply a bead of exterior construction adhesive to each joist.
2. Fasten outside edge of the first deck board using screws supplied. Drill and countersink a 3mm pilot hole along the outer side of the deck board at each joist intersection.
3. Cut a slot in the deck board at each joist intersection using a biscuit cutter with a 4mm cutting blade. Adjust biscuit cutter height so the bottom edge of the fastener is flush with the bottom of the deck board.
4. Place Archideck Fasteners in the slots at each joist intersection.
5. Pre-Drill a 2.5mm pilot hole on a 45 degree angle through each fastener.
6. Install screws in each Archideck Fastener & tighten firmly.



NOTE:

Don't over tighten screws.

Installing Additional Deck Boards

7. Cut a slot in each side of the next deck board at each joist intersection.
8. Apply a bead of exterior construction adhesive to each joist.
9. Place the deck board so the slot slips over the exposed Archideck Fastener.
10. Repeat steps 4, 5 & 6



NOTE:

Don't over tighten screws

11. Repeat above process until all decking is fastened with the exception of the final outside board which requires slots cut on the inside only.
12. Secure the final board in the same manner as installing the first board.



-ATTENTION-

To minimise timber shrinkage please ensure that the deck boards have acclimatized to the ambient surroundings. It is strongly recommended all timber decking receive high quality exterior timber protection products. Please research deck material installation data provided by your timber supplier or deck manufacturer prior to installation.

Please follow relevant building regulations/codes in your state or territory.